



Samsung ATIV Book 4 Screen Replacement

This guide will show how to replace the screen of this laptop.

Written By: Daniel



INTRODUCTION


If your laptop is experiencing display issues such as bad resolution, flickering, or black dots, and/or is physically damaged or broken, replacing the screen may solve these problems.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Screen




- Be sure the computer is off, and open the computer so that the screen is showing.
- Use the plastic opening tool and pry away the casing surrounding the screen. Remove the casing entirely.

Step 2




- Remove the four 3.5mm screws securing the screen.
- ⚠ Tilt the screen back before removing the screws, there is a possibility it could fall and damage your keyboard or the ribbon cable connected to it.

Step 3



- Place the screen gently on the keyboard.

Step 4



- Remove the ribbon cable from the screen.
- Remove and replace the screen.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-20 08:40:32 AM.